HOME
DECORATORS
C O L L E C T I O N

HDC# 16602 MFG# TW-19356WO
CARSON DINING TABLE 30"Hx48"Wx48"D WASHED OAK

ASSEMBLY INSTRUCTIONS

Note: 1. Before assembly, please be sure to work on a soft, flat surface to avoid any damage to the finish.
2. You need at least 2 people to finish the assembly of this product.

Made In China



BEFORE ASSEMBLY

IMPORTANT NOTE: READ CAREFULLY BEFORE ASSEMBLY TO PREVENT DAMAGE TO PARTS. FOLLOWING INSTRUCTIONS LISTED BELOW IN THE PROPER SEQUENCE AS NUMBERED TO ASSURE FAST, EASY AND CORRECT ASSEMBLY.

THANK YOU FOR PURCHASING THIS QUALITY PRODUCT. BE SURE TO CHECK ALL PACKING MATERIAL CAREFULLY FOR SMALL PARTS, WHICH MAY HAVE CAME LOOSE INSIDE THE CARTON DURING SHIPMENT. COUNT ALL PARTS AND MATERIAL HARDWARE, COMPARE WITH PARTS LIST TO BE SURE ALL PARTS ARE PRESENT. IF ANY PARTS ARE MISSING OR DAMAGED, PHONE, FAX OR MAIL TO OUR CUSTOMER SERVICE DEPARTMENT. FOR EFFICIENT AND SPEEDY SERVICE, PLEASE INDICATE THE MODEL NUMBER AND CODE LETTER OF PART NEEDED.

HARDWARE LIST

ROUND HEAD BOLT 48 PCS  (1)	ROUND HEAD BOLT FLAT WASHER 4 SETS  (2)		

PARTS LIST

TOP PANEL 1 PC  A	METAL RING 1 PC  B	METAL RING 1 PC  C	METAL RING 1 PC  D
LEG 16 PCS E			

NOTE: THE SURFACE WITH THE STICKER IS THE BACK SIDE.

ASSEMBLE TOP PANEL (A), METAL RING (B & C & D) AND LEG (E)

- USE ROUND HEAD BOLT AND FLAT WASHER (2) TO ASSEMBLE METAL RING (B) AND TOP PANEL (A) TOGETHER.
- USE ROUND HEAD BOLT (1) TO ASSEMBLE METAL RING (B & C & D) AND LEG (E) TOGETHER.

CONNECT ALL SIXTEEN LEGS (E) TO THE THREE METAL RINGS (B, C, AND D). DO NOT FULLY TIGHTEN UNTIL ALL LEGS ARE IN PLACE.